

Sprl Flema – Rue Outre 46
7910 Anvaing – Belgium
Tel : +32 (0)69/67.27.87
Fax : +32 (0)69/67.27.80

USER MANUAL ROLLING SHUTTER VR60

MAINTENANCE AND REPLACEMENT OF PARTS of FIRE-PROOF ROLLING SHUTTERS

A rolling shutter should be maintained and checked regularly to ensure safe operation and use. This is described in the EN-Norms.

GENERAL:

- 1/ The components which are attached to the cables are under extreme tension.
If not handled properly, injuries or damages might occur !

So, working on these components may only be carried out by qualified overhead-door mechanics!

- 2/ Replacement of broken or weared components should always be done by qualified overhead-door mechanics.
- 3/ When checking the door, always disconnect the electrical main power supply. Make sure that it is blocked against re-engaging without you knowing it.

REGULAR MAINTENANCE:

➤ After installation:

- 1/ Grease running part of the guides
- 2/ Grease the bearings
- 3/ Grease the rubbers slightly with vaseline

Mechanic
Mechanic
User

➤ After 3 months:

- 1/ Complete visually inspection

User

Sprl Flema – Rue Outre 46
7910 Anvaing – Belgium
Tel : +32 (0)69/67.27.87
Fax : +32 (0)69/67.27.80

➤ Every 6 months:

1/ Check side seals on damage or wear and tear	User
2/ Check top seal on damage or wear and tear	User
3/ Check bottom seal on damage or wear and tear	User
4/ Grease all above mentioned points	User
5/ Clean the slats	User
6/ Remove dirt and waste from the door or its surroundings	User
7/ Check cables on damage or wear	User

➤ Every 12 months:

1/ Check side seals on damage or wear and tear	Mechanic
2/ Check top seal on damage or wear and tear	Mechanic
3/ Check bottom seal on damage or wear and tear	Mechanic
4/ Grease all above mentioned points	Mechanic
5/ Clean the slats	Mechanic
6/ Remove dirt and waste from the door or its surroundings	Mechanic
7/ Check cables on damage or wear	Mechanic

➤ After max. 2 years:

In order to ensure a safe and problemfree use of the fireproof rolling shutter, It is essential to change the 24V-batteries **every two year**.

➤ After cable break:

- Replace cable with its connections
- Adjust tension if needed

Do not touch any connection or part of the rolling shutter after a cable break.
In the event of disturbance or of alarm, do not use anymore the shutter,
Call immediately the supplier and wait until qualified mechanics arrive at the scene!

Use following specifications for greasing : PTFE or SAE20

Use for cleaning : Soft soap with water. Do not use high-pressure water-cleaning. Do not use aggressive soap or cloth.